


# ARPES Sample Mounting




The APS **does not have**  
any Laue capability

Top hat sample plate:





Flat sample plate:



# ARPES Sample Mounting

Flat Cu sample plate with Mo-plate:



The scratches are from the sample receiver in the load-lock. If your sample or of Ta foil extends past the use 12 mm x 12 mm area, your sample will broken/removed or will get stuck.

